J-Bus Device

OBD Device

FleetSharp

STOP

WE'RE CONFIDENT WE CAN MAKE IT RIGHT!
If you have any questions or problems with your GPS tracker, please give us a call before you make a return.
FleetSharp Customer Support Phone: 1-877-899-2939
Email: support@fleetsharp.com

How are we doing? We'd love to know.
We hope you will be pleased with your order and the service you receive. We love to hear from customers about features they love, and ways we can continue to improve your experience.
Leave us a review where you made your purchase.
Thank you!

For more valuable information, please like us on Facebook and follow us on LinkedIn.

Activate Your Device

1 Open a web browser and go to:
www.fleetsharp.com/getstarted

2 Create an account, or log in to your existing account.

New Customers
Fill out the following to complete your registration:

Activation Code:
E-mail Address:
Create Your Password:
Confirm Password:
☐ I agree to the Terms & Conditions

Next

Already a Customer?
Simply log in and we'll walk you through the process of adding your new units.

Email Address:
Password:

Sign In
Forgot Your Password?

If not already on file, you may be prompted for your billing information.

Here's your device activation code:

Sticker Goes Here

3 Follow the instructions for activating your device(s).

Make sure the activation code in this guide matches the code on screen. Or, if your activation code does not show up re-enter it and press continue.

Set Up eFleetSuite

4 Login to the ELD eFleetSuite login page. Sign in using the eFleetSuite credentials emailed to you. Please allow 2-3 business days for delivery.

5 Set up your home terminal(s).

A Select 'Home Terminals' in the 'ADMIN' dropdown.

Home Terminals

ADMIN SETTINGS
HOME HOS DVIR
Devices
Home Terminals   ow Deleted
Filter By: <None>
Organization Detail   New Import
View
Users
Home Terminal Name   User Roles   **Adjust for DST**
☐ Canada Terminal   License Key   Enabled
☐ Main Terminal   Enabled

B Click 'New.'

Home Terminal Name: *
Time Zone: *   --Select Time Zone--   ☑ Adjust for DST
Address 1: *
Address 2:
City: *
State / Province: *   -- Select State / Province --
ZIP / Postal Code: *
Phone:

Save Cancel

C Fill out the form, then click 'Save.'

6 Set up your driver(s). Make sure you have the driver's license number available.

A Select 'Drivers' in the 'SETUP' dropdown.

Drivers

DVIR SETUP ADMIN SETTINGS
Asset Types   ☐ Show Deleted
Filter By: <Non
Assets   New Import Delete
View
Asset Groups
Driver   Drivers   **Home Terminal**   **Driver Type(s)**
☐ GRAHAM, ROBERT   Driver Groups   Main Terminal   US 8-day property-carrying
☐ HOLMAN, AVARICE   Locations   Main Terminal   US 8-day property-carrying
☐ JESSIE, RINALDO   Main Terminal   US 8-day property-carrying
☐ LOVELACE, DAVID   LOVD26   Main Terminal

B Click 'New.'

HOS DVIR SETUP ADMIN SETTINGS

C Your drivers will use 'Driver ID' to log in to the app.

required field.

Save Cancel

Driver Details
Driver ID: *
First Name: *
Middle Initial:

E Complete the form, then click 'Save.'

Web Access
☑ Permit Web Access

D Make sure to check the box to give Web Access to drivers.

The system will create a temporary password for the driver. See the Driver's App Guide for details.

Install Your Device

7 You will need your device, the cord, and the tablet. If you have ordered more than one tablet, you may choose any tablet that you have received, as these have not been paired yet. Begin with the ignition and the tablet powered off.

8 **J-BUS Devices:** Connect the cord to the device, then plug the device into the J-Bus port.

OBD Devices: Connect the OBD extension cord to the device, then plug the device into the OBDII port.

9 Turn on the ignition, and verify green and orange lights on the device.

10 Power on the tablet. The app will automatically start. The tablet will then recognize all devices within range. The device at the top of the list will be the one closest to you. Double check by matching the serial number, then choose the device.

11 **OBD devices only** - A pop-up window will prompt you to input the current odometer reading of the vehicle.

Your installation is complete!

Per regulation, for the first 10 days the system may not display available hours on the tablet. The system is still capturing information and generating logs, which are available in the eFleetSuite portal.

Get to Know the FleetSharp ELD System

Click HOS or DVIR for a description of each log, checklist, and report available.

Make your driver and date selections above, then click 'View Logs' to see Driver Logs.

Driver Logs

ME   HOS ▶   DVIR ▶   SETUP ▶   ADMIN ▶   SETTINGS ▶

Driver: GRAHAM, ROBERT (GRAR87)   **Date:** 5/4/2017   ...   < Previous Day   Next Day >

View Logs   Print   View Edits

Record Date: 5/4/2017 CDT
24-Hour Starting Time: 12:00 AM
Time Zone Offset: UTC-05:00

Carrier: Agilis Demo
USDOT Number: -
16305 Swingley Ridge Rd #100
Chesterfield, MO 63017

Home Terminal: Main Terminal
1301 5th St #105
Coralville, IA 52241

Driver: GRAHAM, ROBERT
Driver ID: GRAR87
Multiday Basis: 8 Days

Print/Display Date: 5/4/2017

MID-NIGHT 1 2 3 4 5 6 7 8 9 10 11 NOON 1 2 3 4 5 6 7 8 9 10 11

OFF — 13:56
SB — 00:00
D — 00:00
ON

Total Distance Driven Today: 0 mi (0 km)

Vehicle IDs / VINs
None

Resources   Edit

Co-Drivers (IDs)

— Legend —
Edited Status   Gap

Inspection Checklist

HOME   HOS ▶   DVIR ▶   SETUP

Asset Type: Vehicle

View   New Part   New Defect

Choose a part, then click here to add a new possible defect which your drivers need to inspect.

Click here to add a new part to your driver's inspection list.

Defects
- 📁 Brakes (Parking)
  - ⚠ Other
  - ⚠ Slow to release
  - ▷ ⚠ Weak or ineffective
  - ▷ ⚠ Will not release
- 📁 Brakes (Service)
  - ▷ ⚠ Air compressor not working
  - ▷ ⚠ Chatters, shudders or vibrates
  - ▷ ⚠ Dragging
  - ▷ ⚠ Leaking air
  - ▷ ⚠ Leaking fluid
  - ▷ ⚠ Other
  - ▷ ⚠ Overheating or running hot
  - ▷ ⚠ Seized
  - ▷ ⚠ Warning light not working
  - ▷ ⚠ Warning light on
  - ▷ ⚠ Weak or ineffective
- 📁 Coupling Devices
  - ▷ ⚠ Fifth wheel cracked or damaged
  - ▷ ⚠ Other
- 📁 Emergency Equipment

Name:
Brakes (Parking)

Code:

Codes will appear in parentheses following the part or defect.

Save   Delete

Want to learn more about the FleetSharp ELD system?

Visit the help pages in your ELD portal to sign up to attend one of our informative webinars!